



# ASUS ZenWatch New Strap Installation

How to replace your ASUS ZenWatch strap with an aftermarket strap.

Written By: Steven Miller





## TOOLS:


- [1.5 mm Flathead Screwdriver](#) (1)



## PARTS:

- [22mm Watch Strap](#) (1)
- [22mm spring bars](#) (2)

## Step 1 — New Strap Installation



- Take new watch strap and springbars, insert one side into the hole on watch case.
- Using the 1.5mm flat head screwdriver compress the spring bar until you can slide the band in between the bars on the watch case.

---

This document was last generated on 2017-06-17 09:16:44 PM.